

PathWave
FPGA 2020

Release Notes

Notice

© Keysight Technologies, Inc. 2019

1400 Fountaingrove Pkwy., Santa Rosa, CA 95403-1738, United States

All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause.

Use, duplication or disclosure of Software is subject to Keysight Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Portions of this software are licensed by third parties including open source terms and conditions. For detail information on third party licenses, see [Notice](#).

Table of Contents

2020 Highlights	5
2019 Highlights	6
2018 Highlights	7
Licensing	8
BSP Compatibility	9
Known Issues	10
System Requirements.....	13
Recommended Hardware Configurations	13
Software Compatibility with PathWave FPGA.....	13
Summary of HDL Language Support	14
Installation.....	15
Obtain PathWave FPGA License File	15
Download PathWave FPGA Installer	15
Install PathWave FPGA.....	15
PathWave FPGA License Setup	15
Node-locked License	16
Floating License.....	16
Launch PathWave FPGA	16

This section contains information about previous and current releases.

2020 Highlights

This section provides a general overview of the new features present in release 2020:

- Verilog parameter support. See *Verilog Support* in the [User Guide](#).
- Enabling register stages at the sandbox boundary. See *Registering Sandbox Interfaces* in the [User Guide](#).

2019 Highlights

This section provides a general overview of the new features present in release 2019:

- Enabled re-targeting a project from one BSP to another. See *Migrating a design to a new BSP* in the [User Guide](#).
- Added hierarchical design support through Sub-modules. See *Creating a New Submodule Project* in the [User Guide](#).
- Added new IP to the included base IP. See *PathWave FPGA IP Repository* in the [User Guide](#).
- Parsing of IP-XACT 2009 enabled. Xilinx Vivado blocks will now use the interfaces present in the block.
- Created a tool for packaging HDL code into IP-XACT 2014. See *IP Packager* in the [User Guide](#).

2018 Highlights

This section provides a general overview of the new features present in release 2018, the first release of PathWave FPGA:

- PathWave FPGA is a graphical environment that provides a way to rapidly develop FPGA designs on Keysight Open FPGA hardware.
- An IP library is provided which includes Logic/Math, Memory, and DSP blocks that can be included in an FPGA design. Vivado IP blocks or custom HDL IP can also be imported and the port interfaces described using IP-XACT 2014.
- PathWave FPGA provides a design flow from schematic to bitfile generation with the press of a button.

Licensing

- PathWave FPGA requires: a) **version 2018.04** of the EEs of EDA licensing software, b) version **>=2018.04** codewords, and c) the licensing server software, **lmgrd** and **agileesofd**, must be at least the same versions as those included in EEs of EDA Licensing software **2018.04**. PathWave FPGA will not start if any of these requirements is not met.
- In the EEs of EDA License Tools version 2018.04, the licensing vendor daemon (**agileesofd**) is upgraded to sync up with FlexNet FNP **11.13.1.4** version of FLEX license manager (**lmgrd**). The PathWave FPGA installer for the Windows platform will automatically set up these two new license server daemons by default for local node-locked license users. For more information, refer to [Licensing FAQs](#).
- For more details, refer [Licensing For Administrators](#).

BSP Compatibility

PathWave FPGA is compatible with all BSPs, but there are several minor issues.

The **M3202 3.73** release and the **M3302 3.64** release both contain a block called "Streamer32x2." Every time you load or create a project with one of these BSPs you will get an error dialog because PathWave FPGA also contains the same block. We recommend that you do one of the following to fix the issue.

- If you do not want to use the streamer block while using PathWave FPGA then follow these steps:
 - For the M3202 **delete** the folder: C:\Program Files\Keysight\M3202A BSP\R037300\bsp\ip\7k325\streamer32x2 and **delete** C:\Program Files\Keysight\M3202A BSP\R037300\bsp\ip\7k410\streamer32x2
 - For the M3302 **delete** the folder: C:\Program Files\Keysight\M3302A BSP\R036400\bsp\ip\7k325\streamer32x2 and **delete** C:\Program Files\Keysight\M3302A BSP\R036400\bsp\ip\7k410\streamer32x2
- If you do want to use the streamer block while using PathWave FPGA then follow these steps:
 - For the M3202 **delete** the folder: C:\Program Files\Keysight\M3202A BSP\R037300\bsp\ip\7k325\streamer32x2 and **move** C:\Program Files\Keysight\M3202A BSP\R037300\bsp\ip\7k410\streamer32x2 to an IP repository. This IP repository must be used in PathWave FPGA 2018, but must not be used in PathWave FPGA 2020.
 - For the M3302 **delete** the folder: C:\Program Files\Keysight\M3302A BSP\R036400\bsp\ip\7k325\streamer32x2 and **move** C:\Program Files\Keysight\M3302A BSP\R036400\bsp\ip\7k410\streamer32x2 to an IP repository. This IP repository must be used in PathWave FPGA 2018, but must not be used in PathWave FPGA 2020.

The **M3102A 1.35** release and the **M3202A 3.67** release build scripts contain hard-coded paths to the PathWave FPGA 2018 **k7z_generator.exe** program. This will cause a failure if PathWave FPGA 2018 is not installed. To fix this for this and future PathWave FPGA releases, do the following:

- Navigate to the BSP script folder; this is typically C:\Program Files\Keysight\M3102A BSP\R013500\bsp\script for the **M3102A** or C:\Program Files\Keysight\M3102A BSP\R036700\bsp\script for the **M3202A**.
- Open the sd_common_build.tcl file in a text editor; this may require administrator privileges.
- Change the line at or around line 437 from:


```
set k7zGenerator {C:/Program Files/Keysight/PathWave FPGA 2018/k7z_generator.exe}
```

 to:


```
set k7zGenerator [file join $script_dir k7z_generator.exe]
```
- Copy the following files from the PathWave FPGA 2020 install directory (typically C:\Program Files\Keysight\PathWave FPGA 2020) to the BSP script directory:
 - 7za.exe
 - k7z_generator.exe
 - KsfCore-0.dll

Known Issues

- IP block 'Streamer32x2b' requires Vivado 2018.1 minimum. Use the 'Streamer32x2' IP block with earlier versions of Vivado.
- **Backward Compatibility**
 - In PathWave FPGA 2019 release or earlier, MEM interface was treated as having a byte-addressing scheme. From this release forward, MEM interfaces are using a word-addressing scheme. This change has the following impact to a project created with an earlier release and used with the current one:
 - if the project contained interface instances that were using the MEM interface but originating from a byte-addressing design interface (like AXIMM), the maximum acceptable value for the address width of the each instance has been lowered by 2 bits. This might cause the selected address width value to fall out of range. The user needs to manually adjust the value.
 - if the project contained a register bank originating from a MEM interface, the address offset difference between each register is reduced from 4 to 1.
 - In PathWave FPGA 2019 release or earlier, "TO range" ports were broken out into individual wires on the schematic. This behavior has been removed. This change has the following impact to a project created with an earlier release and used with the current one:
 - any connections on a "TO range" port will be lost.
- Submodule designs may contain design interfaces with extraneous ports which do not get connected during a build even if they are connected on the schematic. This happens when a interface has disabled optional ports which are mandatory for the same interface, but with a different interface role.
 - For example, if you created a slave aximm with "arprot" and "awprot" disabled in the submodule interfaces dialog, then the design interface inside the submodule will be a master and will contain "arprot" and "awprot" because they are mandatory for masters, but they will not be connected to anything no matter what at built time. If you need them then enable them in the submodule interfaces dialog.
 - This will give a critical warning that looks like "Driverless net found. Design will not pass DRC check. Router will skip net ..."
- Using multiple monitors with different display scaling can result in issues with the PathWave FPGA UI. We recommend using the same scale factor for all monitors. Below are known issues, but there are likely others:
 - Window does not auto adjust when moving between monitors with different resolutions (e.g. 4K to 2K).
 - Title bar buttons do not respond to user interaction when moved from a 4K monitor to a non-4K monitor if text scaling set at 150% or above.
 - Window cuts off sections of the program on 4K monitors with text scaling set at 250% or above.
 - White border is present around maximized window on 4K monitors with text scaling set at 250% or above.
 - Changing display scaling while PathWave FPGA is running is not recommended and may not work correctly.
- **VHDL support**
 - The value range of an Integer datatype of a port is ignored. Directly importing such a file in PathWave FPGA will be completed successfully, however, the synthesis of any design that contains that IP will fail. A workaround is to create an IP-XACT file

for the VHDL file using the IP Packager. Then, in the Physical Ports tab, modify the width to match the actual width required.

- Some VHDL errors are ignored by PathWave FPGA when importing VHDL, but will fail during synthesis. Vivado is the authority on whether a VHDL file is valid, not PathWave FPGA.
 - For vector ports with a 'downto' range, the right boundary must be literal '0'. For a 'to' range, the left boundary must be literal '0'.
 - Constants or datatypes imported from another package cannot be used in the entity declaration.
 - When Kactus2 is used for creating IP-XACT for a VHDL file, the VHDL entity declaration must end with "end <entity_name>" and not "end entity."
 - Arrays are not supported. They may or may not load into the schematic properly, but they will not build properly.
- **Verilog support**
 - Importing Verilog IP into PathWave FPGA has a number of known limitations. It is recommended that you create IP-XACT for any Verilog IP that does not meet the following conditions. Note that only module declarations, port and parameter definitions and 'endmodule' are checked. A violation of the following conditions will produce a "Syntax Error" message when importing Verilog IP:
 - Module declarations must include at least one port definition.
 - Ports and parameters cannot have the same name differing only by case (e.g. "myPort" and "myport").
 - Tasks and functions are not supported because their ports are misinterpreted as part of the module's interface.
 - Output registers cannot be assigned an initial value in the same statement where it is defined, such as "output reg myReg = 0;"
 - Definition of port attributes is not supported, such as "(* attribute definition *) input portName,".
 - Port ranges only support expressions with addition, multiplication, division, subtraction and parenthesis. As a workaround, the expression can be moved to a parameter and the port range defined using that parameter.
 - Parameters and port definitions in a module declaration may not be conditionally included using `ifdef / `endif statements and they cannot use any preprocessor variables.
 - Expressions are limited to 32-bit signed integers. For example, "'hFFFF_FFFF" is treated as -1 instead of 4294967295.
 - Size constants in expressions are ignored. For example, "4'd65" is treated as 65 instead of being truncated to 1.
 - Arrays will fail to parse and will not load.
 - When using the Vivado IP tool, Vivado's *Tools > Settings > IP > Default IP Location* setting must be set to <Local to Project>. Otherwise, PathWave FPGA will not be able to find and import the IP.
 - When using PathWave FPGA remotely on a Windows 7 machine, the frames of the main window and any other dialog of the application may lose their special PathWave FPGA appearance to a more Windows-style one.
 - Arrays are not supported in ipxact, but may load without giving any errors.

- No interconnect exists for MEM interfaces. In the M3202A & M3102A projects this shows up as disallowing multiple memory mapped instances of HVI ports. One Memory mapped port or any number of registers may be placed, but not both at the same time.
 - The program will allow you to place the blocks, but at build time an error will be displayed saying that no MEM interconnect exists.
- Literals are restricted to 64 bits in this release. A '1' in the uppermost bit of the 64 bits can be represented with a hexadecimal or binary representation, or a negative decimal.
- UNC paths are not supported for building FPGA bits.
 - A UNC path can be mapped to a windows drive for building, but this is discouraged due to slow FPGA build times on remote file systems.
- If you run into intermittent licensing errors using a network license server, it could be because of a short timeout. Increasing the environment variable FLEXLM_TIMEOUT to 20000000 will set the timeout to be 20 seconds.
 - If licensing errors do not stop, a local node locked license will solve the issue.
- Saving and loading from a path with unicode characters is not supported.
- IP-XACT with callouts to unused HDL files can cause FPGA builds to fail.
- Using enumeration names longer than 150 characters can cause the IP Packager to crash
- For the LO5_DC and LO5_UC library IP blocks, the tunable range for the LO frequency is limited to $f/f_s = \pm 0.4$.

System Requirements

You must ensure that your system meets the following requirements before installing PathWave FPGA.

- Administrator privileges
- Operating system that has the most recent updates and Service Packs
- License File (or Authorization Codes, or token if evaluating) or internet access

Recommended Hardware Configurations

Category	Practical Minimums	Recommended
Operating System	Windows 7 SP1, 64-bit (Windows 8 is not supported)	Windows 10, 64-bit
Hard disk	10 GB free space	100 GB free space
RAM	4 GB RAM	16 GB RAM and above
Display	1280 x 720	1920 x 1200
Software Security	USB hardware key	Wired LAN, or Wireless LAN
Test Instrument Interface	Not required	LAN
Touch User Interface	N/A	Not supported

Software Compatibility with PathWave FPGA

The following table summarizes PathWave FPGA compatibility with various versions of other software applications. However, for the latest vendor information, licensing, and downloads, please contact each vendor directly.

Vendor	Software / Feature	Release Officially Supported	May work, but not supported	Release Explicitly not-supported
<u>Xilinx</u>	Vivado, debugging, compilation of bit images.	Vivado 2017.3		prior to Vivado 2017.3
<u>CMake</u>	CMake to support to enable FPGA bit file verification	3.9 or later		prior to 3.9
<u>Kactus2</u>	To Import HDL with collapsible interfaces using IP-XACT	3.6 or later	3.5 (note, there is a workaround documented when using parameterized HDL)	3.4
<u>Microsoft</u>	Visual Studio C++ to enable FPGA bit file verification	2017	Other versions	


Summary of HDL Language Support

Standard	Release Officially Supported	May work, but not supported	Release Explicitly not-supported
IP-XACT	IEEE 1685-2014 , IEEE 1685-2009		
Verilog	IEEE 1364-2005		
VHDL	IEEE 1076-2002 (VHDL 2002)		IEEE 1076-2008 (VHDL 2008)

Newer versions of Xilinx Vivado might be required for Keysight Instruments (BSPs). Consult the instrument product manual for specific requirements.

Installation

PathWave FPGA can be installed on a computer running Windows by downloading the PathWave FPGA install file from <http://www.keysight.com/find/pathwave-fpga>. For the system requirement details, refer to [System Requirements](#).



Obtain PathWave FPGA License File

PathWave FPGA requires a license to run. You can either apply for an [Evaluation](#) or a [Purchased](#) license. Once the license request is approved, a license file (with .lic extension) is sent as an email attachment. Save this file on your computer at `C:\Users\Public`.

Download PathWave FPGA Installer

Click <https://www.keysight.com/find/pathwave-fpga> to download the installer.

Install PathWave FPGA

To install PathWave FPGA, you must have system administrator privileges. Run the downloaded installer and follow the guided tour to complete the installation. If you want to do a silent install, run the installer executable from the command line as **Administrator** and use the "`--mode unattended`" command line option.

PathWave FPGA License Setup

At the end of installation, the **License Setup Wizard** starts automatically after detecting that you do not have a valid license to start PathWave FPGA. If you choose to skip the license

setup, you can complete the process later by clicking **Start > Programs > Keysight PathWave FPGA <release_number> > PathWave FPGA <release_number> License Manager**.

Node-locked License

To setup a counted license, select the **Add or replace a license file** option and follow the guided tour to complete the license setup process. In case of a USB dongle, attach the dongle to the USB port and invoke the **License Manager** to complete the setup process.

CAUTION	You must have system administrator privileges to setup node-locked licenses (Only) on Windows 7 machines.
----------------	---

Floating License

To setup a floating license, select the **Add or replace a network license server** option and follow the guided tour to complete the license setup process. Consult your license administrator for the network path of the license server.

Launch PathWave FPGA

To run PathWave FPGA, go to the **Start** menu and choose **Programs > Keysight PathWave FPGA <release_number> > Keysight PathWave FPGA <release_number>**.